Using the Gateway Exchange Protocol

Tutorial Session 2

Stephen C. Wills

August 13, 2013



Subscribing to Measurements

🕼 openPDC Manager - RitchieThinkPad\Ritchie											
6 or	penPD	C Ma	nager					Current N	ode: Default	-	
Home	Devices	Outputs	Gateway	Adap	oters	Monitoring	Manage				6
Graph Rea	I-time Measuremen	ts									
Refresh I	nterval: 10 sec L	ast Refresh:	05:36:09.978	1		StatusFlag Re	eference D	isplay Settings Sa	ave Display Settings	Load Disc	olav Settings
I ▲ <u>I</u>	DIRECT CONNEC	TED			-						Real-time
- 40	SHELBY Edi	t			60.04-		Y-FQ				
	SHELBY-DF	-0.26			60.02-						
	SHELBY-DV1	0		ł							
V	SHELBY-FQ	59.974 H	łz		- 60 - 60						
	SHELBY-PA1	-159.69	Degrees		й 						
	SHELBY-PA2	-159.66	Degrees		59.98-		Λ.		MAAA	A . AA	14
	SHELBY-PA3	12.246 D)egrees		59.96-	TWM	MM	MM NH~~	NUVVI	mm	MMMM.
	SHELBY-PA4	-158.604	Degrees			05:36:12.000		**		(05:36:17.133
	SHELBY-PA5	152.133	Degrees		ID	Signal	Reference	Time Tag	Value	Unit	
	SHELBY-PM1	299432.78	31 Volts		PPA:2	SHELBY-FO	2	05:36:17.200	59.974	Hz	* ^
	SHELBY-PM2	298438.87	75 Volts								
	SHELBY-PM3	233.086	Amps								






Primary Data Flow

Publication APIs Subscription APIs






Primary Data Flow (cont.)







Internal/External







Gateway Exchange Protocol (GEP)

- GEP is an extremely simple, small and fast wire format than can be used to exchange data points without a fixed predefined configuration – that is:
 - Points arriving in one data packet can be different than those arriving in another data packet. This can be due to each point having a different delivery schedule – or a dynamic schedule (e.g., alarms).
- GEP is a signal level publish/subscribe protocol with two available channels:
 - Command Channel (TCP)
 - Data Channel (UDP or TCP)





Synchrophasor Data Protocol Comparisons

	IEEE C37.118	IEC 61850	GEP
Deployment Zones <i>Today</i>	Substation Control Center Inter-company	Substation Control Center	Control Center Inter-company
Preconfigured Data Packet Format	Yes	Yes – but client definable	No
Security Options	No	Yes	Yes
Signal Level Publish / Subscribe	No	Yes – but not dynamic	Yes





Example Interoperability Layers


Utility Layer	Example	Challenges	
Inter-Reliability Coordinator	GEP	High Volume at Low LatencyDynamic Configuration	
Inter-Operating Center	GEP IEEE C37.118	 Configuration Management 	
Control Center	GEP IEEE C37.118	 System Integration 	
Device / Substation	IEEE C37.118 IEC 61850	Device interoperabilityDevice performance	





What are the requirements?


 GEP must move a *continually variable* set of points at low latency – to be successful, around 1 million points per second.
 1 million assumes 12



- 1 million assumes 12 associations and 100 PMUs (in and out)
 = ~ 0.5 M points in / sec
 - ~ 0.5 M points out / sec
- As of SIEGate 1.0 and openPDC 2.0, over 3,350,000 measurements per second can be accommodated.











Simple Optimizable Structure

- Measurement data is well structured and can be safely condensed into a simple data structure (per signal):
 - 16-bit ID (established at connection)
 - Time (condensed where possible)
 - Value (32-bit real number)
 - Flags
- A highly effective lossless data compression is optionally enabled for the time-series data:
 - Implements an Xor based back-tracking compression algorithm to remove repeating bytes





Buffer Block

- Buffer block measurements define a block of data, rather than a simple measurement value
- GEP can transmit buffer blocks to transfer serialized data in chunks
- SIEGate uses buffer blocks for filebased transfers through GEP





Options for Connecting with GEP

- To get data "into" an application you can use GEP using a variety of API options: – C++
 - Java
 - .NET
 - Mono.NETUnity 3D





GEP Security Modes

- Transport Layer Security Mode
 - TCP command channel is secured using TLS certificates exchanged out of band
 - Optional UDP data channel is secured using rotating keys exchanged over TLS command channel
 - Measurement access restricted on a per subscriber basis
- Gateway-to-Gateway Security Mode
 - TCP command channel is secured using symmetric AES encryption – keys exchanged out of band
 - Optional UDP data channel is secured using rotating keys exchanged over encrypted command channel
 - Measurement access restricted on a per subscriber basis
- Internal Access Mode (No Encryption)
 - Data transferred openly (ideal for internal connections or VPN transfers when connection is already encrypted)
 - Measurement access is unrestricted





Steps to Exchange Data


1. Subscriber creates an authorization request

- Generates an SRQ file
- Send the SRQ file out-of-band (email, thumb drive, CD, etc.)
- 2. Publisher imports SRQ file
 - Authorizes subscriber to connect, but still cannot subscribe
- 3. Publisher authorizes subscriber to subscribe to measurements
 - Publisher can control which measurements that subscriber can see
- 4. Subscriber subscribes to measurements
 - Subscriber can control which measurements that subscriber needs to see





Subscriber Creates an Authorization Request







Publisher Imports SRQ File



	1000
ome Publication Subscription Inputs	uts






Publisher Authorizes Subscriber to Subscribe to Measurements

			You	I	
	Available M	easurement	ts		
	Selected: 1			Search	Advanced
		ID	Point	t Tag	
		DEVARCH	TVA_TESTDEVICE-D	DELL:ABBIH	Test Devic
		DEVARCH	TVA_TESTDEVICE:A	BBF	Test Devic
		Authorize	TESTDEVICE:A	Test Devic	
h	V				Test Devic
J			TVA_TESTDEVICE:A		Test Devic
			TVA_TESTDEVICE-0		Test Devic
2			TVA_TESTDEVICE-0		Test Devic
		DEVARCH	TVA_TESTDEVICE-E	BUS1:ABBV	Test Devic
		DEVARCH	TVA_TESTDEVICE-0	DELL:ABBI	Test Devic
		DEVARCH	TVA_TESTDEVICE-L	.AGO:ABBI	Test Devic
		DEVARCH	TVA_TESTDEVICE-E	BUS1:ABBVH	Test Devic
		DEVARCH	TVA_TESTDEVICE:A	BBS	Test Devic
		DEVARCH	TVA_TESTDEVICE-E	BUS2:ABBVH	Test Devic
	٠				►
	< <	<	1 of	2	> >>





Subscriber Subscribes to Measurements







DataPublisher API Usage

Purpose: SEND

- Attach to publisher events
- Initialize publisher
- Start publisher
- Queue new measurements for processing





Example DataPublisher API Code

namespace DataPublisherTest

Ė

```
{
    class Program
        static DataPublisher publisher = new DataPublisher();
        static Ticks lastDisplayTime;
        static object displayLock = new object();
        static void Main(string[] args)
            // Attach to publisher events
            publisher.StatusMessage += publisher StatusMessage;
            publisher.ProcessException += publisher ProcessException;
            publisher.ClientConnected += publisher ClientConnected;
            // Initialize publisher
            publisher.Name = "dataPublisher";
            publisher.UseBaseTimeOffsets = true;
            publisher.Initialize();
            // Start publisher
            publisher.Start();
```

ThreadPool.QueueUserWorkItem(ProcessMeasurements);





DataSubscriber API Usage

Purpose: Receive

- Attach to subscriber events
- Set up subscription info objects
- Initialize subscriber
- Start subscriber connection cycle
- Handle new measurement data





Example DataSubscriber API Code

```
static void Main(string[] args)
{
    if (args.Length < 2)
    {
        Console.Error.WriteLine("Error: requires two command line arguments");
        Console.Error.WriteLine(" 1. hostname of publisher");
        Console.Error.WriteLine(" 2. port used to initiate connection");
        return;
    }
</pre>
```

```
// Set up subscription info object
```

unsynchronizedInfo.FilterExpression = "FILTER ActiveMeasurements WHERE SignalID LIKE '%'";

```
// Attach to subscriber events
subscriber.StatusMessage += subscriber_StatusMessage;
subscriber.ProcessException += subscriber_ProcessException;
subscriber.ConnectionEstablished += subscriber_ConnectionEstablished;
subscriber.ConnectionTerminated += subscriber_ConnectionTerminated;
subscriber.NewMeasurements += subscriber_NewMeasurements;
```

```
// Initialize subscriber
```

```
subscriber.OperationalModes |= OperationalModes.UseCommonSerializationFormat |
    OperationalModes.CompressMetadata |
    OperationalModes.CompressSignalIndexCache |
    OperationalModes.CompressPayloadData;
```

```
subscriber.ConnectionString = string.Format("server={0}:{1}", args[0], args[1]);
subscriber.Initialize();
```

```
// Start subscriber connection cycle
subscriber.Start();
```





Live Demos

• Subscribing from a .NET C# application

Subscribing from a C++ application (Linux)

Subscribing from a Java application

Subscribing from the Unity platform



